

KidSwitch™

Providing a Helping Hand to Little Ones and Their Parents! Since 1995

Instructions:

(Contains Small Parts / Not A Toy)

1 Place a piece of masking tape (See Diagram #1) vertically down one side of the switch plate to hold it in place against the wall, in order to avoid exposure and contact with electrical wiring.


2 Turn off the circuit breaker (See Diagram #2) that controls the receptacle to which you wish to add KidSwitch™. (NOTE: You should always turn off the appropriate circuit breaker, or the main power breaker when working on any electrical outlet.)

3 Remove the two screws that secure the switch plate to the electrical outlet. Utilizing the new screws supplied, install KidSwitch™ (See Diagram #3). The new screws should be just snug enough to hold the device firmly, while allowing easy up and down movement.


4 Carefully remove all masking tape as not to harm your wall finish.

5 Use and enjoy KidSwitch™!

• Diagram 1



• Diagram 2



• Diagram 3

